



### User Guide


This guidance should be read in conjunction with the IFU supplied with the specific Breathing Circuit, the Flow Driver and Heater Humidifier



**Step 1**




**Step 2**




**Step 3**



**Step 4**



**Step 5**



**Step 6**

